

TRACK, ANALYZE & IMPROVE FLEET OPERATIONS

ALL-IN-ONE FLEET MANAGEMENT SOFTWARE

Geotab Integration

Seamlessly integrate your Geotab devices with Fleetio.



Get automatic odometer readings.

Odometer readings automatically sync every day or use the one-click option to manually trigger a sync at any time.



Resolve failed inspection items with maintenance workflows.

Automatically create issues from failed inspection items from your Geotab DVIRs. Quickly assign service work for a speedy repair and resolution.



Report on fuel location exceptions.

Fuel card transactions are automatically compared against actual vehicle location and geolocation differences exceeding a certain threshold are flagged. Get a daily email summary and detailed map visualization.



Manage Diagnostic Trouble Codes (DTC) & engine faults.

Get an email notification of new fault codes (with the option to ignore) and create an Issue in Fleetio from a fault code with one click.



Set your current vehicle location in Fleetio.

Easily see a vehicle's current location right on the vehicle profile page in Fleetio.



Navigate seamlessly between systems.

View a vehicle's current location directly from its vehicle profile in Fleetio or use the "View in Fleetio" button in Geotab to navigate to the vehicle profile in Fleetio.

Geotab Integration Setup

Setting up the Geotab integration is simple.

New GPS Integration ×

Provider

Geotab

Username

Password

Database

Serial Number	Hardware	Vin	Assignment
0731448	550731448		2011 Ford F150 ↻
0731448	550731315		<div><p>Please Select <input type="text"/></p><p><input type="radio"/> 2011 Ford F150</p><p><input checked="" type="radio"/> 2002 Ranger Supercab</p><p><input type="radio"/> 2001 Chevy G Series 1500</p></div> ↻
0731448	550729476		↻
0731448	550728617		↻
0731448	550728421		2001 Chevy G Series 1500 ↻

Step 1

An Admin user on a Fleetio account can go to the GPS Integrations section of the Account Settings area and add their Geotab credentials.

Step 2

All Geotab devices are then listed and can be mapped to the appropriate vehicles in Fleetio.



Visit our Help Center for full details:

help.fleetio.com/article/122-geotab